

AQtivate 200 setting and configuration



AQtivate 200 is a setting and configuration software suite for AQ-200 series products.

- IED setting and configuration
- User-level password protection
- Online and offline editing of IED configurations
- Uploading and downloading of data
- A connection through Ethernet (ports on both front and rear panels)

Technical Data

GENERAL

The AQtivate 200 software tool is a program for setting and configuring Arcteq AQ-200 series relays. The program uses a modern graphic interface for user-friendly configuration creation. AQtivate 200 can be used both for reading configurations and for writing them into a device. It can also be used for reading disturbance recordings from the device; the recordings can be further evaluated by using the AQViewer software which is included in the AQtivate 200 software suite. Relay settings are stored as an .aqs file which includes all configurations that a user can set. These .aqs files can be saved and stored on a hard drive. You can edit the IED configurations both online and offline. The AQtivate 200 software suite can be downloaded from Arcteq's website for free.

Application Drawing

The screenshot displays the 'Online Edit' interface for a device. On the left, a sidebar contains navigation options: 'General' (selected), 'Protection', and 'Control'. The main area shows the 'Device Info' tab with the following configuration details:

Field	Value	Icon
Device name	AQ-F215 Feeder Protection	**
Device location	Arcteq Relays	**
Serial number	222	-
SW version	v1.0.7-35-g6dccaab	-
HW conf.	AQ-F215-PH0-BB1	-
Timesync. source	Internal	**
Enable stage forcing	Disabled	***
Language	English	**